

Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

<u>Omron</u> XY2B-1006

For any questions, you can email us directly: <u>sales@integrated-circuit.com</u>



OMRON


Assembly Tooling and Accessories

Tooling

XG


■ XG4 / XG2 - Flat Cable Sockets and Bus Connectors

IDC Press



IDC Press Attachments for terminating XG4M and XG2A

XY2B-1007





Applicable Socket

XG4M (All contacts)

XG2A (All contacts)

Operation

XG4M-series Connectors must be placed face down into the locator slot of the Attachment. (With the XG2A Series, place the terminal block in the Attachment.)

Insert the cable until it is flush against the cable stopper. Connections are made by pulling the handle towards you until it stops. For details on operation, see the user's manual supplied with the IDC Tool.

Note: An additional head attachment or spacer is not needed to terminate the XG4M and XG2A connectors.


IDC Press Attachments for XG4E

XY2B-1004 Base attachment for the XG4E			XY2B-14		
1	IDC Tool	Base Attachment	Spacer	Applicable Plug	
	XY2B-0002	XY2B-1004	XY2B-1401	XG4E-10□1/-10□2 XG4E-1431/-1432	
			XY2B-1402	XG4E-1631/-1632 XG4E-2031/-2032	
			XY2B-1403	XG4E-2631/-2632 XG4E-3031/-3032	
			XY2B-1404	XG4E-3431/-3432	
			XY2B-1405	XG4E-4031/-4032	
			XY2B-1406	XG4E-50 1/-50 2	
			XY2B-1407	XG4E-60□1/-60□2 XG4E-54□1/-64□2	

Operation

XG4E-series Connectors must be placed face down into the locator slot of the Attachment. Insert the cable until it is flush against the cable stopper. Next set the proper spacer for the Plug.

Connections are made by pulling the handle towards you until it stops.





OMRON

■ XG5 - Discrete Wire Sockets

Manual IDC Termination Tool

XY2B-7006




This tool is a compact, light-weight model, ideal for use in the laboratory or for maintenance.

Specifications

Applicable connector	XG5M-N	
Applicable wire	AWG24 to AWG28 (with an insulation outer diameter of 1.1 to 1.3 mm)	
Dimensions	25 (W) × 100 (L) × 80 (H)	
Weight	Approx. 180 g	

Automated Wire IDC Tool Set

XY2B-2104-N



Contact Removal Tool XY2E-0001



Used to remove contacts, which need to be replaced or reconfigured, from the housing.

This Wire IDC Tool Set is designed for XG5 Discrete-wire Connectors.

Specifications


Stroke	13 mm
Motor speed	83/100 rpm (50/60 Hz)
Feed pitch	2.54 mm
Operation	Foot switch
Weight	About 6 kg
Rated voltage	0.5 A, 100 VAC (50/60 Hz)
Fuse	1 A
Dimensions	120 \times 200 \times 225 mm (W \times H \times D)

Note: For function and operation details, see the user's manual for the Pressure Welder provided separately.

Replacing Contacts

Use only this tool to remove incorrect IDC contacts.

- 1. Remove the cover.
- 2. Insert the tool into the housing lance holes and push the lance into the housing.
- 3. Pull out the contact while holding the lance down.
- 4. Insert a new contact.



Applicable Connectors and Wires

	Size No.	Applicable wires			
Applicable Connector		UL file No.	Size [No. of wires/diameter] (mm)]	Cross-sectional area (mm)	Covering diameter (mm)
XG5M-031-N XG5M-032-N XG5M-033-N	No. 1	UL1061	AWG24 [7/0.203]	0.21	1.10
XG5M-DD34-N	5M-🗆 35-N No. 2	UL1007	AWG26 [7/0.16]	0.13	1.30
XG5M-□□35-N XG5M-□□36-N			AWG28 [7/0.127]	0.09	1.22

Note: Use only wires specified in the table above

78



Accessories - XG4 / XG5 / XG8

External Polarization Options

The following optional accessories can be used to provide polarization to sockets and plugs that do not have molded polarizing guides and slots built into their housings and shrouds.

Solutions for Shrouded Connectors

XG4Z-0004 Polarizing Key

Typically, 10 contact versions of the XG4A, XG4E and XG4C are available with or without polarizing guides.

Install the XG4Z-0004 polarizing key on XG4A pcb sockets, XG4E plugs and XG4C pcb sockets that do not have a polarizing slot, to prevent reverse connection with XG4M cable sockets that do not have a polarizing guide.

For all other versions, the molded polarity guides and slots can be used by themselves to help prevent reverse insertion. However, use the polarizing key with these versions as well for best results.


How to use There is it. PBT resin (ULV94V-0)/white Polarizing Key Polarizing Key std

Note: Each XG4Z-0004 has 4 Polarizing Keys.

Solutions for Unshrouded Connectors

Use the XG4Z-0005 coding pin to fill a specific hole in one of the XG4 or XG5 sockets. Then, use the XY2E-0002 cutting pin to remove the corresponding terminal from an XG8 unshrouded plug. (See XG5 and XG8 datasheets for details about those connectors.)

XG4Z-0005 Coding Pin



Note: 1. A contact with a Coding Pin inserted cannot be used.2. Each XG4Z-0005 has 4 Polarizing Keys.

XY2E-0002 Contact Cutting Driver

The Contact Cutting Driver is used to cut (twist off) a contact on the mating Plug when using an XG4Z-0005 Coding Pin. How to use




■ Cock Lever State is: Polyamide resin UL94V-2)/natural Lock Lever Lock L

■ XG5 - Spare Contacts

XG4M

Polarity guide hole



Lever into the guide hole

Model	Order in Multples of
XG5W-0031-N	100
XG5W-0034-N	

Note: 1. These Contacts can be used as replacements if a wrong connection is made.

 The applicable wire for size No. 1 is AWG24 (UL-1061). The applicable wire for size No. 2 is AWG26 to AWG28 (UL-1007).

XG4M

XG4C



OMRON

All sales are subject to Omron Electronic Components LLC standard terms and conditions of sale, which can be found at http://www.components.omron.com/components/web/webfiles.nsf/sales_terms.html

ALL DIMENSIONS SHOWN ARE IN MILLIMETERS. To convert millimeters into inches, multiply by 0.03937. To convert grams into ounces, multiply by 0.03527.



55 E. Commerce Drive, Suite B Schaumburg, IL 60173

847-882-2288

Cat. No. X304-E-1

11/10

Specifications subject to change without notice

Printed in USA

OMRON ON-LINE

Global - http://www.omron.com

USA - http://www.components.omron.com

XG Assembly Tooling and Accessories