

Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

[PanaVise](#)
[751371307](#)

For any questions, you can email us directly:

sales@integrated-circuit.com

INDASH by PANAVISE®

751371307

Page 1 of 2

MOUNTING LOCATION:

Right side of radio JR

TOOLS REQUIRED:

Dash Tool, Hook Tool
 Phillips Screwdriver

PARTS INCLUDED:

- (1) S7-1941 Mount
- (3) A - #8x9/16" Needle Pt. Screw

CELL PHONE & MEDIA MOUNT

INSTALLATION INSTRUCTIONS

PART#: 751371307

MFG: TOYOTA/FORD/MERCURY/MAZDA

MODELS & YEARS:

TOYOTA - Tundra 07-13, Sequoia 08-13

FORD - Edge 07-10, Escape 08-12

MERCURY - Mariner 08-11

MAZDA - Tribute 08-11 (Pg.2)

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

Start Here for Toyota Tundra/Sequoia:

STEP #1: With hook tool, insert it deep into the upper right corner of the Instrument Panel & Audio-Video bezel. Pull to release (1) clip by the air vent at the top. Continue to pull to release (1) clip by the fan control, 4WD switch is included with the bezel. With hook tool release the climate control by inserting hook tool into upper left corner, pull to release (1) clip. Continue releasing climate control and a total of (4) clips.

STEP #2: With hook tool/Dash tool remove the cubby below the climate control by inserting it between the climate control and top of the cubby bezel, pull to release (4) clips. Work your way to the bottom of the bezel to release (2) more clips. Pull bezel straight out to remove cubby.

STEP #3: Remove the radio by removing (4) 10mm bolts below the radio. Pull out the radio to release (3) clips on top of the radio. Set radio down onto a cloth.

STEP #4: Place InDash by PanaVise Mount on the right side of the radio cavity into the slot it fits best. See Picture. Install the (3) supplied screws.

STEP #5: Replace the radio/climate control/cubby bezels, and then snap in the Instrument Panel starting at the bottom.

INSTALLATION IS COMPLETE. ENJOY YOUR NEW INDASH BY PANAVISE MOUNT.



Bezel released-Note AC Knob



AC Bezel released w/ Dash Tool



(4) Radio bolts Location



Final Installation Picture



InDash Installation Location



05-26-15

INDASH by PANAVISE®

751371307

Page 2 of 2

MOUNTING LOCATION:

Right side of radio JR

TOOLS REQUIRED:

Dash Tool, Hook Tool

Phillips Screwdriver

PARTS INCLUDED:

- (1) S7-1941 Mount
- (3) A - #8x9/16" Needle Pt. Screw

**CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS**

PART#: 751371307

MFG: TOYOTA/FORD/MERCURY/MAZDA

MODELS & YEARS:

TOYOTA - Tundra 07-13, Sequoia 08-13

FORD - Edge 07-10, Escape 08-12

MERCURY - Mariner 08-11

MAZDA - Tribute 08-11

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.



Radio Climate Control, Air Vent, Bezel Removed

Start Here for Ford Edge:

STEP #1: With hook tool, remove the bezel that goes from the top of the dash (with tray), down to, and includes the climate control and air vents. Start at the bottom to release (2) clips. Continue up to the top of the bezel releasing a total of (10) clips.

STEP #2: Place the InDash by PanaVise Mount on the right side of the vent cavity. Install the (3) screws supplied.

STEP #3: Replace the radio/climate control /air vent bezel.



Final Installation Picture - Edge



InDash Installed, Mounting Location - Edge

Start Here for 2008's, Ford Escape, Mercury Mariner, Mazda Tribute :

STEP #1: With hook tool, remove air vent assembly by inserting hook tool/dash tool into the side and pull to release (4) clips. Set assembly aside.

STEP #2: Place InDash by PanaVise Mount on the right side of the air vent cavity and install the (3) supplied screws. Replace the radio/climate control /air vent bezels.



Air Vent Assembly Removed



Final Installation Picture - 08 Mariner, Escape, Tribute

Mount Installed Location 08 Mariner, Escape, Tribute



Suggested Mounting Location



05-26-15