Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

Maxim Integrated MAX1926ETC+

For any questions, you can email us directly: sales@integrated-circuit.com

Features



19-2556; Rev 1; 10/02



Switch-Mode 1-Cell Li+ Chargers



General Description

The MAX1925/MAX1926 single-cell lithium-ion (Li+) switch-mode battery chargers use an external PMOS pass element step-down configuration. Charge current is programmable, and an external capacitor sets the maximum charge time.

Additional features include automatic input power detection (ACON output), logic-controlled enable, and temperature monitoring with an external thermistor. The MAX1925 disables charging for inputs greater than 6.1V, while the MAX1926 charges for inputs between 4.25V and 12V.

The MAX1925/MAX1926 feature two precondition levels to restore near-dead cells. The devices source 4mA to a cell that is below 2V while sourcing C/10 to a cell between 2V and 3V. Full charge current is then applied above 3V. A CHG output drives an LED to indicate charging (LED on) and fault conditions (LED blinking).

The MAX1925/MAX1926 are available in a 12-pin 4mm × 4mm thin QFN package and are specified over the extended temperature range (-40°C to +85°C). An evaluation kit is available to speed design.

Applications

Digital Cameras Self-Charging Battery Packs **PDAs** Cradle Chargers


♦ Small (4mm × 4mm) Package

- ♦ 4.25V to 12V Input Range (MAX1926)
- ♦ Overvoltage Lockout at 6.1V (MAX1925)
- ♦ ±0.75% Battery Regulation Voltage
- ♦ Set Charge Current with One Resistor
- ♦ Automatic Input Power Sense
- ♦ LED (or Logic-Out) Charge Status and Fault Indicator
- ♦ Programmable Safety Timer
- ♦ Autorestart at Cell = 4V
- **♦ Thermistor Monitor Input**


Ordering Information

PART	TEMP RANGE	PIN- PACKAGE	INPUT CHARGING RANGE
MAX1925ETC	-40°C to +85°C	12 Thin QFN 4mm x 4mm	4.5V to 6.1V
MAX1926ETC	-40°C to +85°C	12 Thin QFN 4mm x 4mm	4.25V to 12V

Pin Configuration



Typical Operating Circuit



MIXIM

Maxim Integrated Products 1

For pricing, delivery, and ordering information, please contact Maxim/Dallas Direct! at 1-888-629-4642, or visit Maxim's website at www.maxim-ic.com.



ABSOLUTE MAXIMUM RATINGS

IN, INP, ACON to GND	0.3V to +14V
CHG, EXT to PGND	0.3V to (V _{INP} + 0.3V)
CS, BATT, EN, THRM to GND	0.3V to +6V
CT to GND	0.3V to +4V
EN, THRM, CT to IN	14V to +0.3V
INP to IN	0.3V to +0.3V
PGND to GND	0.3V to +0.3V
CS to BATT	0.3V to +0.3V
EXT Continuous RMS Current	±100mA

Continuous Power Dissipation ($T_A = +70^{\circ}C$)	
Exposed Paddle Soldered to Board	
(derate 16.9mW/°C above +70°C)	1349mW
Exposed Paddle Unsoldered	
(derate 9mW/°C above +70°C)	721mW
Operating Temperature Range	40°C to +85°C
Junction Temperature	+150°C
Storage Temperature Range	65°C to +150°C
Lead Temperature (soldering, 10s)	+300°C

Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

ELECTRICAL CHARACTERISTICS

 $(V_{PGND} = V_{GND} = 0, V_{INP} = V_{IN} = V_{\overline{CHG}} = 5V, V_{BATT} = V_{CS} = V_{EN} = 4V, THRM = 10k\Omega$ to GND, $C_{CT} = 100nF$, $T_A = 0^{\circ}C$ to +85°C, unless otherwise noted. Typical values are at $T_A = +25^{\circ}C$.)

PARAMETER		CONDITIONS	MIN	TYP	MAX	UNITS	
Supply Voltage Range	V _{INP} , V _{IN} (MAX1925 does not charge above 6.1V)				12.0	V	
	M. M. dalas	MAX1925	4.30	4.50	4.78		
ACON TO BUT	V _{INP} , V _{IN} rising	MAX1926	4.00	4.25	4.50	j ,,	
ACON Trip Point	Marie Marie falling	MAX1925	4.17	4.30	4.43	V	
	V _{INP} , V _{IN} falling	MAX1926	3.90	4.15	4.40		
IND IN Chutdows Throshold	MAX1925	Rising	5.8		6.4	V	
INP, IN Shutdown Threshold	IVIAX 1925	Falling	5.3		5.9	v	
EN Input Resistance	MAX1926 internal	ly pulled up to 3V	125	300	550	kΩ	
EN Leakage Current	MAX1925		-1		+1	μΑ	
EN Logic Input High Threshold			2			V	
EN Logic Input Low Threshold					0.8	V	
BATT + CS Input Current (Total Current into BATT and CS)	DONE state, V _{BAT}		25	50			
	EN = GND (Note 1)			2	10	μΑ	
(Total Current into BATT and C3)	VBATT = VINP = VI		2	10			
CS Input Current	Charging			39		μΑ	
	EN = GND		5	8	mA		
INL. IND Total Input Current	VBATT = VINP = VIN = 4V, shutdown			2	10	μΑ	
IN + INP Total Input Current	VBATT = 4.1V; cha	VBATT = 4.1V; charging			10		
	$V_{BATT} = 4.3V$; dor		5	8	mA		
VOLTAGE LOOP							
Voltage Loop Set Point			4.1685	4.2000	4.2315	V	
Voltage Loop Hysteresis				15		mV	
BATT Prequal1 Voltage Threshold			1.9	2	2.1	V	
BATT Prequal2 Voltage Threshold				3	3.15	V	



ELECTRICAL CHARACTERISTICS (continued)

 $(V_{PGND} = V_{GND} = 0, V_{INP} = V_{IN} = V_{\overline{CHG}} = 5V, V_{BATT} = V_{CS} = V_{EN} = 4V, THRM = 10k\Omega \text{ to GND, } C_{CT} = 100nF, \textbf{T_A} = \textbf{0}^{\circ}\textbf{C} \text{ to } +\textbf{85}^{\circ}\textbf{C}, unless otherwise noted. Typical values are at <math>T_A = +25^{\circ}\text{C}.$)

PARAMETER	CONDITIONS	MIN	TYP	MAX	UNITS
Restart Threshold	Charging restarts when BATT falls to this point	3.92	4.00	4.08	V
BATT Voltage Fault Threshold	If BATT exceeds this threshold, EXT is high (external MOSFET is off) and CHG blinks	4.275	4.350	4.425	V
CURRENT LOOP		•			
CS - BATT Sense Threshold	V _{CS} - V _{BATT} , average value	132	142	152	mV
CO - BATT Sense Threshold	Rise/fall hysteresis		30		1117
Prequal1 Charge Current	V _{BATT} < 2V	3	4	6	mA
Prequal2 CS - BATT Sense	Average value, 2V < V _{BATT} < 3V (charge current is C/10)		14		mV
Threshold	Rise/fall hysteresis, 2V < VBATT < 3V		12		IIIV
Current Threshold for Full-Battery Indication	I _{LOAD} falling, as percentage of fast charge current	6	12	20	%
DRIVER FUNCTIONS					
EXT Sink/Source Current			1		А
EXT On-Resistance	EXT high or low		5	12	Ω
Nominal Switching Frequency	V _{BATT} = 3.6V, L =10μH		235		kHz
TIMER FUNCTIONS	•				
Full-Time Timeout - tFULL	C _{CT} = 100nF		3.02		hours
Prequal1 Timeout	C _{CT} = 100nF		tFULL/1088 (10s)	3	s
Prequal2 Timeout	C _{CT} = 100nF	(t _{FULL/17} 10.67 mir	n)	min
Timer Accuracy	C _{CT} = 100nF for 3 hours	-15		+15	%
CHG Output Low Current	VCHG = 1V	7	10	14	mA
CHG Output High Leakage Current	V _{CHG} = 12V			1	μА
CHG Blink Rate - Fault	Fault state (50% duty cycle), C _{CT} = 100nF		0.5		Hz
ACON High Leakage	VACON = 12V		0.01	1.00	μΑ
ACON Sink Current	VACON = 0.4V	2			mA
THERMISTOR MONITOR (Note 2	2)				
THRM Sense Current for Hot Qualification		344.1	352.9	361.7	μА
THRM Sense Current for Cold Qualification		47.58	48.80	50.02	μΑ
THRM Sense-Voltage Trip Point	(Note 3)	1.386	1.400	1.414	V





ELECTRICAL CHARACTERISTICS

 $(V_{PGND} = V_{GND} = 0, \ V_{INP} = V_{IN} = V_{\overline{CHG}} = 5V, \ V_{BATT} = V_{CS} = V_{EN} = 4V, \ THRM = 10k\Omega \ to \ GND, \ C_{CT} = 100nF, \ \textbf{T_A} = \textbf{-40}^{\circ}\textbf{C} \ to \ \textbf{+85}^{\circ}\textbf{C}, \ unless otherwise noted. Typical values are at T_A = +25^{\circ}C.) \ (Note 4)$

Supply Voltage Range V _{INP} , V _{IN} (MAX1925 does not charge above 6.1V) 4.5 ACON Trip point V _{INP} , V _{IN} rising MAX1925 4.30 V _{INP} , V _{IN} falling MAX1926 4.0 V _{INP} , V _{IN} falling MAX1925 4.17 MAX1926 3.9 Rising 5.8 Falling 5.3 EN Input Resistance MAX1925 internally pulled up to 3V 125 EN Leakage Current MAX1925 -1 EN Logic Input High Threshold 2 2 EN Logic Input Low Threshold 2 2 BATT + CS Input Current (Total Current into BATT and CS) DONE State, V _{BATT} = 4.1V EN = GND (Note 2) VBATT = V _{INP} = V _{IN} = 4V, shutdown (Note 1) EN = GND IN + INP Total Input Current VBATT = V _{INP} = V _{IN} = 4V, shutdown VBATT = 4.1V, charging VBATT = 4.3V, done	12.0 4.78 4.5	V
Vinp, Vin rising MAX1926 4.0		
MAX1926 4.0	4.5	
VINP, VIN falling MAX1925 4.17		V
NAX1926 3.9	4.43	V
INP, IN Shutdown Threshold MAX1925 Falling 5.3 EN Input Resistance MAX1926 internally pulled up to 3V 125 EN Leakage Current MAX1925 -1 EN Logic Input High Threshold EN Logic Input Low Threshold BATT + CS Input Current (Total Current into BATT and CS) IN + INP Total Input Current VBATT = VINP = VIN = 4V, shutdown VBATT = VINP = VIN = 4V, shutdown VBATT = 4.1V, charging	4.4	
EN Input Resistance MAX1926 internally pulled up to 3V 125 EN Leakage Current MAX1925 -1 EN Logic Input High Threshold 2 EN Logic Input Low Threshold 2 EN Logic Input Low Threshold DONE State, VBATT = 4.1V EN = GND (Note 2) VBATT = VINP = VIN = 4V, shutdown (Note 1) EN = GND VBATT = VINP = VIN = 4V, shutdown VBATT = 4.1V, charging	6.4	V
EN Leakage Current MAX1925 -1 EN Logic Input High Threshold 2 EN Logic Input Low Threshold DONE State, VBATT = 4.1V BATT + CS Input Current (Total Current into BATT and CS) EN = GND (Note 2) VBATT = VINP = VIN = 4V, shutdown (Note 1) EN = GND IN + INP Total Input Current VBATT = VINP = VIN = 4V, shutdown VBATT = 4.1V, charging VBATT = 4.1V, charging	5.9	ľ
EN Logic Input High Threshold EN Logic Input Low Threshold BATT + CS Input Current (Total Current into BATT and CS) IN + INP Total Input Current VBATT = VINP = VIN = 4V, shutdown VBATT = V.INP = VIN = 4V, shutdown VBATT = 4.1V, charging	550	kΩ
EN Logic Input Low Threshold BATT + CS Input Current (Total Current into BATT and CS) $IN + INP Total Input Current$ $VBATT = VINP = VIN = 4V, shutdown (Note 1)$ $EN = GND$ $VBATT = VINP = VIN = 4V, shutdown$ $VBATT = VINP = VIN = 4V, shutdown$ $VBATT = 4.1V, charging$	+1	μΑ
BATT + CS Input Current (Total Current into BATT and CS) $IN + INP Total Input Current$ $DONE State, V_{BATT} = 4.1V$ $EN = GND (Note 2)$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown (Note 1)}$ $EN = GND$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown}$ $V_{BATT} = 4.1V, \text{ charging}$		V
BATT + CS Input Current (Total Current into BATT and CS) $EN = GND \text{ (Note 2)}$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown (Note 1)}$ $EN = GND$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown}$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown}$ $V_{BATT} = 4.1V, \text{ charging}$	0.8	V
(Total Current into BATT and CS) EN = GND (Note 2) VBATT = V _{INP} = V _{IN} = 4V, shutdown (Note 1) EN = GND VBATT = V _{INP} = V _{IN} = 4V, shutdown VBATT = V _{INP} = V _{IN} = 4V, shutdown VBATT = 4.1V, charging	50	
$V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown (Note 1)}$ $EN = GND$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown}$ $V_{BATT} = V_{INP} = V_{IN} = 4V, \text{ shutdown}$ $V_{BATT} = 4.1V, \text{ charging}$	10	μΑ
IN + INP Total Input Current	10]
IN + INP Total Input Current VBATT = 4.1V, charging	8	mA
$V_{BATT} = 4.1V$, charging	10	μΑ
V _{BATT} = 4.3V, done	10	A
	8	mA
VOLTAGE LOOP		
Voltage Loop Set Point 4.158	4.242	V
BATT Prequal1 Voltage Threshold 1.9	2.1	V
BATT Prequal2 Voltage Threshold 2.85	3.15	V
Restart Threshold Charging restarts when BATT falls to this point 3.92	4.08	V
BATT Voltage Fault Threshold If BATT exceeds this threshold, EXT is high (external MOSFET is off) and CHG blinks 4.275	4.425	V
CURRENT LOOP		
CS - BATT Sense Threshold V _{CS} - V _{BATT} , average value 127	157	mV
Prequal1 Charge Current VBATT < 2V 3	6	mA
Current Threshold for Full-Battery Indication ILOAD falling, as percentage of fast charge current 4	20	%
DRIVER FUNCTIONS		
EXT On-Resistance EXT high or low	12	Ω
TIMER FUNCTIONS		
Timer Accuracy C _{CT} = 100nF for 3 hours -16	40	
CHG Output Low Current VCHG = 1V 7	+16	%

4 ______*NIXI/*U



ELECTRICAL CHARACTERISTICS (continued)

 $(V_{PGND} = V_{GND} = 0, V_{INP} = V_{IN} = V_{\overline{CHG}} = 5V, V_{BATT} = V_{CS} = V_{EN} = 4V, THRM = 10k\Omega$ to GND, $C_{CT} = 100nF$, $T_A = -40^{\circ}C$ to $+85^{\circ}C$, unless otherwise noted. Typical values are at $T_A = +25^{\circ}C$.) (Note 4)

PARAMETER	CONDITIONS	MIN	TYP	MAX	UNITS
CHG Output High Leakage Current	V _{CHG} = 12V			1	μΑ
ACON High Leakage	VACON = 12V			1	μΑ
ACON Sink Current	$V\overline{ACON} = 0.4V$	2			mA
THERMISTOR MONITOR					
THRM Sense Current for Hot Qualification		342		363	μΑ
THRM Sense Current for Cold Qualification		47.3		50.3	μΑ
THRM Sense-Voltage Trip Point	(Note 3)	1.379		1.421	V

- Note 1: When the AC adapter is unplugged or if the charger is shut down, BATT drain is less than 10µA.
- Note 2: These specifications guarantee the thermistor interface detects a fault at the correct temperature (0°C to +5°C cold temperature and 45°C to +50°C hot temperature) with Philips NTC Thermistor Series 640-6, 2322-640-63103, 10.0K at +25°C, ±5% (or equivalent).
- Note 3: A fault is generated if V_{THRM} lower than 1.4V during the cold test or higher than 1.4V during the hot test. Hot and cold tests occur on alternate CT clock transitions.
- Note 4: Specifications to -40°C are guaranteed by design and not production tested.


6



Switch-Mode 1-Cell Li+ Chargers

Typical Operating Characteristics


(Circuit of Figure 1, V_{SUPPLY} = 5V, V_{BATT} = 4V, T_A = +25°C, unless otherwise noted.)








Typical Operating Characteristics (continued)


(Circuit of Figure 1, V_{SUPPLY} = 5V, V_{BATT} = 4V, T_A = +25°C, unless otherwise noted.)



















Pin Description

PIN	NAME	FUNCTION
1	CHG	Charge Status LED Driver. Open-drain LED driver sinks 10mA when the MAX1925/MAX1926 are charging. CHG also blinks at a 0.5Hz rate during fault states (see the <i>Timing</i> section). High impedance when charger is in shutdown. See Tables 1 and 2.
2	EN	Enable. Drive EN high to enable charger. Logic level input for normal ON/OFF control. In the MAX1926 EN is internally pulled up to 3V with a $300k\Omega$ resistor.
3	THRM	Thermistor Input. Monitors external thermistor ($10k\Omega$ at $+25^{\circ}$ C). When external temperature is lower than 0° C or above $+50^{\circ}$ C, charging stops and the charger enters fault mode. Charging resumes when the temperature returns to normal. During a temperature fault the MAX1926 blinks the \overline{CHG} output, while MAX1925 \overline{CHG} remains off (high).
4	ACON	Power-OK Indicator Output. Open-drain output goes low when AC adapter power is valid. See Table 2 for ACON states.
5	СТ	Timing Capacitor Connection. Connect timer cap to program full-charge safety timeout interval and prequalification fault times. Timeouts with C _{CT} = 100nF are: Full Timer (t _{FULLCHG}): 3 hours—If FASTCHG is not completed within this time a fault is asserted. Prequal2 Timer: Full Timer/17 (10.67 min) Prequal1 Timer: Full Timer/1088 (10s)
6	CS	Charge-Current Sense Input. 142mV nominal regulation threshold. CS is high impedance during shutdown.
7	BATT	Battery-Sense Input. Also negative side of charge-current sense. BATT is high impedance during shutdown.
8	GND	Ground
9	PGND	Power Ground
10	EXT	PMOS Gate-Driver Output. Drives gate of external PMOS switching transistor from IN to GND. When using the MAX1926, ensure that the MOSFET V_{GS} rating is greater than V_{IN} .
11	INP	Supply Voltage Input
12	IN	Supply-Sense Input. Connect IN to INP.

8 ______ NIXINI






Figure 1. Functional Diagram

MIXIM



Detailed Description

The MAX1925/MAX1926 switch-mode battery chargers form a complete solution for a single-cell Li+ battery. The devices include battery undervoltage/overvoltage fault protection. The MAX1925/MAX1926 use EN and THRM for shutdown, battery detection, and temperature monitoring. The devices provide outputs to indicate charge status (CHG) and presence of input power (ACON).

The MAX1925/MAX1926 include two prequalification modes that must be passed before the charger enters the fast-charge state. During fast charge, the charger operates initially in constant-current mode until the battery voltage reaches 4.2V. When the battery voltage has reached 4.2V, the charger operates in constant-voltage mode. In constant-current mode, the charger acts as a hysteretic current source, controlling the inductor's peak and valley currents. In constant-voltage

mode, the charger regulates the peak and valley of the output ripple.

Charge Cycle

The MAX1925/MAX1926 initiate PREQUAL when one of the following occurs:

- When an external power source is connected
- The cell voltage falls to 4V after charging is finished
- · EB is toggled
- Input power is cycled

Some Li+ cells can be damaged when fast-charged from a completely dead state. Moreover, an over-discharged cell may indicate a dangerous abnormal cell condition. As a built-in safety feature, the MAX1925/MAX1926 use a two-level prequalification charge to determine if it is safe to charge. When the cell voltage is less than 2V, the cell is charged from an internal




Figure 2. MAX1925/MAX1926 State Diagram






Figure 3. Charging Current and Voltage Timing Diagrams

linear 4mA current source (PREQUAL1). When the cell voltage exceeds 2V, the cell is charged with 10% of the programmed fast-charge current (IFASTCHG) until it reaches 3V. When the cell voltage is above 3V, fast charging occurs at the full set current. If the cell fails to reach the next prequalification threshold before a set time (see tprequal and tprequal in the Timer Capacitor and Fault Modes section), charging stops, a fault alarm is set, and the CHG output blinks.

Figures 2 and 3 show charging behavior typical Li+ cell. The MAX1925/MAX1926 remain in fast-charge mode until the battery voltage reaches regulation and the

charge current drops below 1/8th of IFASTCHG. The charger then enters full topoff mode and the CHG LED is turned off. In full topoff mode, the controller continues to operate as in fast-charge mode, except that it remains in constant-voltage mode (CVM) unless the battery voltage falls. After every tprequal (see the *Timer Capacitor and Fault Modes* section) the charger enters the Kelvin state (for 2 CT clock cycles, 60ms with CCT = 100nF) where charge current is interrupted so that the battery voltage can be accurately measured.

The MAX1925/MAX1926 do not enter done mode until trullchg has been reached. If the battery is removed





and a new battery is connected during either fast-charge or full topoff modes, the charger begins with full charge current without prequalification unless the part is reset. Detect battery insertion by connecting THRM to a thermistor on the battery, if a thermistor is used, or to a $10 k\Omega$ resistor linked to a battery door mechanism.

Constant-Current Mode (CCM)

When the battery voltage is below 4.2V, the MAX1925/MAX1926 regulate the charging current by controlling the peak and valley inductor currents. When the inductor current exceeds the 158mV/R_{SET}, the MAX1925/MAX1926 turn the external PFET off. When the inductor current falls below 128mV/R_{SET}, the MAX1925/MAX1926 turns the external PFET on, but only if the battery voltage is below regulation. The maximum cell charging current is programmed by selecting the external R_{SET} (see Figure 1) resistor connected between BATT and CS. Select the external resistor value using R_{SET} = 142mV/I_{FASTCHG}.

The accuracy of the charge current is a function of input voltage, battery voltage, inductance, and comparator delay (300ns typ). Determine the charge-current error according to the following equation:

$$\Delta I_{CHG} = \frac{\left(V_{IN} - 2 \times V_{BATT}\right) \times t_{IDelay}}{2 \times L}$$

where ΔI_{CHG} is the charge-current error, and t_{IDelay} is the current-sense comparator delay.

For this reason choose L for an on-time and off-time greater than $2 \times t_{\text{IDelay}}$ to minimize error in the charging current.

Constant-Voltage Mode (CVM)

In constant-voltage mode (CVM), the controller regulates the peak and valley of the output ripple. The maximum cell voltage is regulated to 4.2V. If, for any reason, the cell voltage exceeds 4.35V, a fault alarm is set, the CHG output blinks, and the PFET power switch is held off. The charger can then be restarted only by cycling input power or the EN input.

Indication of Charge Completion (CHG)

The \overline{CHG} output is a 10mA current-sink output that indicates the cell's charging status. Connect an LED from IN to \overline{CHG} for a visible indicator. Alternatively, a pullup resistor (typically $200k\Omega$) from a logic supply to \overline{CHG} provides a logic-level output. Table 1 relates the status of the LED to the condition of the charger and battery.

ACON Output

The \overline{ACON} open-drain output indicates when usable power is applied to IN. In the MAX1926 when V_{IN} exceeds \overline{ACON} threshold (nominally 4.25V with \overline{IN} rising—see the *Electrical Characteristics* table), \overline{ACON} goes low. In the MAX1925, \overline{ACON} goes low when the input voltage is between 4.5V and 6.1V (see Table 2).

Re-Initiating a Charging Cycle

The MAX1925/MAX1926 feature automatic restart that resumes charging when the cell voltage drops to 4V and trull CHG is completed. By automatically resuming charge-

Table 1. CHG Output States

STATE	CONDITION	СНС		
OFF	EN low or no battery or input power	High impedance (LED off)		
PREQUAL1	Charge current = 4mA until BATT reaches 2V.	Low (LED on)		
PREQUAL2	Charge current = C/10 until BATT reaches 3V.	Low (LED on)		
FAST CHARGE	Charge current = C = 142mV/R _{SET} .	Low (LED on)		
FULL CHARGE	Charge current has fallen to C/8.	High impedance (LED off)		
FAULT PREQUAL1	BATT does not reach 2V before PREQUAL1 timeout.			
FAULT PREQUAL2	BATT does not reach 3V before PREQUAL2 timeout.	Blinking. LED on 50% f _{BLINK} (0.5Hz). Can		
FAULT FULL	Charge current does not drop to C/8 before FULL CHARGE timeout.	only be cleared by cycling input power, THRM, or EN.		
FAULT BATT VOLTAGE	Battery voltage has exceeded 4.35V.	Blinking. LED on 50% fBLINK (0.5Hz).		
FAULT TEMP	Temperature has risen above +50°C or fallen below 0°C.	MAX1925—High impedance (LED off)		
FAULT TEIVIP	Temp fault clears by itself.	MAX1926—Blinking (LED on 50% 0.5Hz)		
NONE	Initial power-up or enable with battery not present.	Blinking at rapid rate as charger cycles through RESET, PREQUAL1, and DONE.		



Switch-Mode 1-Cell Li+ Chargers

Table 2. ACON Behavior vs. VIN

PART	V _{IN}	ACON	CHARGING	CHG LED
	$V_{IN} > V_{\overline{ACON}}$ threshold (4.5V nom) and < 6.1V, and $V_{IN} > V_{\overline{BATT}}$	LOW	YES	ON (until charge complete)
MAX1925	V _{IN} > V _{ACON} threshold and V _{IN} < V _{BATT} (Note: This state should never occur)	High Z	NO	OFF
	V _{IN} < V ACON threshold	never occur) High Z NO OFF ON		
	V_{IN} > $V_{\overline{\text{ACON}}}$ threshold (4.25V nom) and V_{IN} > V_{BATT}	LOW	YES	
MAX1926	V _{IN} > V _{ACON} threshold and V _{IN} < V _{BATT} (Note: This state should never occur)	Threshold (4.5V nom) and < 6.1V, and LOW YES ON (until charge completed by threshold and V _{IN} < V _{BATT} at the should never occur) Threshold High Z NO OFF ON (until charge completed by threshold (4.25V nom) and V _{IN} > V _{BATT} Threshold and V _{IN} < V _{BATT} The should never occur) High Z NO OFF	OFF	
	V _{IN} < V ACON Threshold		OFF	

ing when the battery voltage drops, the MAX1925/MAX1926 ensure that the cell does not remain partially charged after use when charger power is available.

Charging also restarts if input power is cycled or if the charger is restarted by the EN or THRM input. If a new battery is inserted, the charger must be restarted. If the THRM functionality is used, the charger is automatically restarted upon battery insertion. When THRM is not used, toggle EN or connect THRM through a resistor to be grounded with a battery-door latch switch.

Applications Information

Timer Capacitor and Fault Modes

The on-chip timer checks charge progress and issues an alarm signal through a blinking CHG output when one of the safety timers times out (see Table 1). All timers are set by one external capacitor at CT. A 100nF value sets the full-charge timer (tfullchg) to 3 hours, the tprequal timer to (tfullchg)/1088 (10s), and the tprequal timer at (tfullchg)/17 (10.67 minutes).

If the charger enters full-charge state (after the charging current has fallen below C/8) before the full-charge timer expires, no fault occurs, but if the timer expires before full charge is reached, a fault is indicated (see Table 1).

A fault is also indicated if the battery voltage exceeds 4.35V. When the cell voltage exceeds 4.35V a fault alarm is set, the CHG output blinks, and the PFET turns off.

To restart the charger after a fault occurs, the fault state must be cleared by toggling EN, or by cycling input power at IN (see Figure 1). Temperature faults do not need to be cleared by EN. The MAX1925/MAX1926 resume charging after the temperature returns to within the set window.

Inductor Selection

Because the MAX1925/MAX1926 is hysteretic, the constant-current mode switching frequency is a function of the inductance, sense resistance, and current-sense hysteresis (30mV, from the *Electrical Characteristics*). To minimize charge-current error:

$$L > \frac{(V_{IN} - 2 \times V_{BATT}) \times t_{Delay}}{2 \times \Delta I_{CHG}}$$

where ΔI_{CHG} is the acceptable charge-current error and should usually be less than 1/4th the full charge current. t_{IDelay} is the current-sense comparator delay (300ns typical). Calculate L for $V_{IN} = V_{IN,MAX}$, $V_{BATT} = V_{BATT,MIN}$, with positive ΔI_{CHG} and $V_{IN} = V_{IN,MIN}$, $V_{BATT} = V_{BATT,MAX}$, with negative ΔI_{CHG} . Use the larger calculated value for L.

The resulting switching frequency in CCM is

$$\begin{split} f_{Switch} > & \left(\frac{I_{HYST} \times L + t_{IDelay} V_{BATT}}{V_{IN} - V_{BATT}} + 2 \times t_{IDelay} + \right. \\ & \left. \frac{I_{HYST} \times L + t_{IDelay} \times (V_{IN} - V_{BATT})}{V_{BATT}} \right)^{-1} \end{split}$$

Choose an inductor with an RMS and saturation current rating according to the following equation:

$$I_{SAT/RMS} > \frac{V_{IPK}}{R_{SET}} + \frac{(V_{IN} - V_{BATT})t_{IDelay}}{L}$$

where VIPK is the peak current-sense threshold (158mV typ).

Output Capacitor Selection

The ESR of the output capacitor influences the switching frequency of the charger during voltage regulation





mode. To ensure stable transition from CCM to CVM choose a capacitor with the following ESR:

$$R_{ESR} > \frac{V_{VHIST}}{V_{IHIST}} \times R_{SET}$$

where V_{VHIST} is the voltage hysteresis (15mV typ) and V_{IHIST} is the current-sense threshold hysteresis (typically 30mV). Tantalum capacitors are recommended. However a ceramic capacitor (typically $10\mu F$) with a series resistor can also be used.

MOSFET Selection

The MAX1925/MAX1926 drive an external P-channel MOSFET's gate from IN to GND. Choose a P-channel MOSFET with a IVDS,MAXI > VIN. Since EXT drives from rail to rail the MOSFET must also be rated for IVGS,MAXI > VIN. At the lower operating frequencies and currents for typical MAX1925/MAX1926 applications resistive and diode losses dominate switching losses. For this reason choose a MOSFET with a low RDSON. The resistive losses are:

$$P_{Resistive_losses} \cong D \times I_{CHG}^2 \times R_{DSON} + I_{CHG}^2 \times (R_{SET} + R_L)$$

where D is the operating duty cycle (V_{OUT}/V_{IN}) and R_L is the inductor resistance. The MOSFET's power dissipation must exceed D \times I_{CHG}² \times R_{DSON}.

Diode Selection

In the event of a short-circuited source, the body diode inherent in the external PFET allows the cell to discharge. To prevent this and to protect against negative input voltages, add a Schottky or silicon diode between the power source and IN.

The MAX1925/MAX1926 use a diode for catching the inductor current during the off cycle. Select a Schottky diode with a current rating greater than V_{IPK}/R_{SET} and a voltage rating greater than V_{IN} .

Dropout Behavior

The MAX1925/MAX1926 regulate charging current by ramping inductor current between upper and lower thresholds, typically 128mV and 158mV across RSET.

This results in an average current of 142mV/Rset. At input voltages near dropout (4.6V at IN for the typical circuit), the inductor current ramp waveform becomes somewhat flattened as inductor, MOSFET, input diode, and battery resistance limit inductor current. When the inductor current waveform flattens, it's average value rises with respect to the upper and lower current thresholds. This creates a slight peak (about 5%) in charging current at high battery voltages as seen in the Charging Current vs. Battery Voltage plot in the *Typical Operating Characteristics*. Charging current is still controlled in dropout and the charger operates normally. The dropout current peak can be minimized by reducing MOSFET and inductor resistance, as well as forward voltage in the input diode.

Thermistor Interface

An external thermistor inhibits charging by setting a fault flag when the cell is cold (<0°C) or hot (>+50°C). The THRM time-multiplexes two sense currents to test for both hot and cold qualification. Connect the thermistor between THRM and GND. If no temperature qualification is desired, replace the thermistor with a $10 k\Omega$ resistor connected through the battery-latch mechanism. The thermistor should be $10 k\Omega$ at +25°C and have a negative temperature coefficient, as defined by the expression below:

$$R_T = R_{25^{\circ}C \times e} \left\{ \beta \left[\left(\frac{1}{T + 273} \right) - \left(\frac{1}{298} \right) \right] \right\}$$

Table 3 shows nominal fault detection temperatures that result from a wide range of available thermistor temperature curves.

For a given thermistor characteristic, it is possible to adjust the fault-detection temperatures by adding a resistor in series with the thermistor or a parallel resistor from THRM to GND.

Chip Information

TRANSISTOR COUNT: 5722 PROCESS: BICMOS


Table 3. Fault Temperature for Different Thermistors

THERMISTOR BETA	3000	3250	3500	3750
Resistance at +25°C	10000Ω	10000Ω	10000Ω	10000Ω
Resistance at +50°C	4587.78Ω	4299.35Ω	4029.06Ω	3775.75Ω
Resistance at 0°C	25140.55Ω	27148.09Ω	29315.94 Ω	31656.90Ω
Nominal Hot Trip Temperature	55.14°C	52.60°C	50.46°C	48.63°C
Nominal Cold Trip Temperature	-3.24°C	-1.26°C	0.46°C	1.97°C



_Package Information

(The package drawing(s) in this data sheet may not reflect the most current specifications. For the latest package outline information, go to **www.maxim-ic.com/packages**.)



MIXIM



Switch-Mode 1-Cell Li+ Chargers

Package Information (continued)

(The package drawing(s) in this data sheet may not reflect the most current specifications. For the latest package outline information, go to **www.maxim-ic.com/packages**.)

	COMMON DIMENSIONS											
PKG	12L 4×4 16L 4×4			ļ	2	20L 4×4			24L 4x4			
REF.	MIN.	N□M.	MAX.	MIN.	N□M.	MAX.	MIN.	N□M.	MAX.	MIN.	N□M.	MAX.
Α	0.70	0.75	0.80	0.70	0.75	0.80	0.70	0.75	0.80	0.70	0.75	0.80
A1	0.0	0.02	0.05	0.0	0.02	0.05	0.0	0.02	0.05	0.0	0.02	0.05
A2	0.20 REF		0.20 REF		0.20 REF							
b	0.25	0.30	0.35	0.25	0.30	0.35	0.20	0.25	0.30	0.18	0.23	0.30
D	3.90	4.00	4.10	3.90	4.00	4.10	3.90	4.00	4.10	3.90	4.00	4.10
E	3.90	4.00	4.10	3.90	4.00	4.10	3.90	4.00	4.10	3.90	4.00	4.10
е		0.80 B20	С.		0.65 BSC		0.50 BSC.			0.50 BSC.		
k	0.25	-	-	0.25	-	-	0.25	-	-	0.25	-	-
L	0.45	0.55	0.65	0.45	0.55	0.65	0.45	0.55	0.65	0.30	0.40	0.50
N		12		16		20			24			
ND		3		4			5			6		
NE		3			4			5			6	
Jedec		WGGB			WGGC			WGGD-	1		WGGD-	2

EXPOSED PAD VARIATIONS						
PKG. CODES	D2			E2		
	MIN.	N□M.	MAX.	MIN.	N□M.	MAX.
T1244-2	1.95	2.10	2.25	1.95	2.10	2.25
T1644-2	1.95	2.10	2.25	1.95	2.10	2.25
T2044-1	1.95	2.10	2.25	1.95	2.10	2.25
T2444-1	2.45	2.60	2.63	2.45	2.60	2.63

IOTES:

- 1. DIMENSIONING & TOLERANCING CONFORM TO ASME Y14.5M-1994.
- 2. ALL DIMENSIONS ARE IN MILLIMETERS. ANGLES ARE IN DEGREES.
- 3. N IS THE TOTAL NUMBER OF TERMINALS.
- 4\text{\text{THE TERMINAL #1 IDENTIFIER AND TERMINAL NUMBERING CONVENTION SHALL CONFORM TO JESD 95-1 SPP-012. DETAILS OF TERMINAL #1 IDENTIFIER ARE OPTIONAL, BUT MUST BE LOCATED WITHIN THE ZONE INDICATED. THE TERMINAL #1 IDENTIFIER MAY BE EITHER A MOLD OR MARKED FEATURE.
- DIMENSION & APPLIES TO METALLIZED TERMINAL AND IS MEASURED BETWEEN 0.25 mm AND 0.30 mm FROM TERMINAL TIP.
- 6 ND AND NE REFER TO THE NUMBER OF TERMINALS ON EACH D AND E SIDE RESPECTIVELY.
- 7. DEPOPULATION IS POSSIBLE IN A SYMMETRICAL FASHION.
- (A) COPLANARITY APPLIES TO THE EXPOSED HEAT SINK SLUG AS WELL AS THE TERMINALS.
- 9. DRAWING CONFORMS TO JEDEC MO220.

PROPRIETARY INFORMATION

TITLE PACKAGE OUTLINE

12,16,20,24L QFN THIN, 4x4x0.8 mm

APPROVAL DOCUMENT CONTROL NO. REV 2

21-0139 A 2

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

6 ______Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600