

Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

[Segger Microcontroller Systems](#)
[8.08.01 J-LINK ARM-14 ADAPTER](#)

For any questions, you can email us directly:
sales@integrated-circuit.com

Embedded Software Solutions

Home
Embedded Software

Development Tools
J-Link ARM

Adapters

- 5V adapter
- JTAG 14 pin adapter
- DFPUs
- Flash breakpoints
- Flash download
- Flash SDK
- GDB Server
- IDE integration
- Interface description
- J-Flash ARM
- J-Link software
- J-Mem
- JTAG Isolator
- Model comparison
- Non-commercial-use
- Performance comparison
- RDI
- SDK
- J-Link ARM Pro
- J-Link ARM Lite
- J-Link Coldfire
- J-Trace ARM
- J-Trace for Cortex-M3

Production Tools

Evaluate our software!

Downloads

Distributors

Customers

Partners

Sales

Forum

About us

Head office Germany

Phone: +49-2103-2878-0
 Fax: +49-2103-2878-28
 E-mail: info@segger.com
 www.segger.com

US office

Phone: +1-978-874-0299
 Fax: +1-978-874-0599
 E-mail: info@segger-us.com
 www.segger-us.com

Development Tools
J-Link ARM
Adapters
JTAG 14 pin adapter

JTAG 14 pin adapter

An adapter is available to use J-Link ARM with targets using this 14 pin 0.1" mating JTAG connector.

Pin	Signal	Pin no. on 20 pin JTAG
1	VTrf	1
2	GND	GND
3	nTRST	3
4	GND	GND
5	TDI	5
6	GND	GND
7	TMS	7
8	GND	GND
9	TCK	9
10	GND	GND
11	TDO	13
12	RESET	15
13	VTrf	1
14	GND	GND

Mapping between the JTAG 14 pin adapter and 20 pin JTAG interface
[Pricing](#)

[Imprint](#) [Disclaimer](#) [Sitemap](#)
[back to top](#)

© 2009, www.segger.com, All rights reserved.