Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

Molex Connector Corporation 0638136100

For any questions, you can email us directly: sales@integrated-circuit.com



Distributor of Molex Connector Corporation: Excellent Integrated System Limited


Datasheet of 0638136100 - EXTRACTION TOOL

Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

Extractor Tool for HDX™ Crimp Female Terminals



Extractor Tool Instruction Sheet Order No. 63813-6100



FEATURES

This Extractor Tool is for the removal of HDX™ Female Crimp Terminals from 15-Way or 30-Way HDX™ Female Module.

SCOPE

Products: HDX[™] Female Crimp Terminal 15-Way and 30-Way, 0.635mm (.025"), AWG 20-24 (0.22-0.60mm²).

Terminal Series No.	Module Order No.			Terminal Order No.	
98587	98627-0001	98627-1001	98627-1002	98587-0013	98587-0014


Warning: Before extracting the crimp terminals, the wire cap assembly will need to be removed.

See ATS-638136300 for instructions. See Figure 1.

The Female Module will also need to be removed from the Standard Frame Module.

See ATS-638136200 for instructions. See Figure 1.

OPERATION:



1. Insert the extractor tool into the module as shown in Figure 2.

Doc No: ATS-638136100 Release Date: 03-09-10 Revision: A Revision Date: 03-09-10




Distributor of Molex Connector Corporation: Excellent Integrated System Limited

Datasheet of 0638136100 - EXTRACTION TOOL

Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

Extractor Tool for HDX™ Crimp Female Terminals

- 2. Use the slots located on the inside of the module to guide the extraction tool blades into the module until contact is made with the terminal.
- 3. Continue to insert the tool, always checking to see that the blades of extraction tool are on the outside of the terminals body.
- 4. Continue to insert extraction tool into module until the locking tabs of the module have been depressed. See Figure 2.
- 5. Gently pull the extractor tool along with the crimped wire, out from the module.
- 6. Molex does not offer repair parts for this Tools due to the inexpensive nature of the tool.



CAUTION: Molex specifications are valid only when used with Molex terminals, modules, and tooling.

Contact Information

For more information on Molex application tooling please contact Molex at 1-800-786-6539.

Americas Headquarters Lisle, Illinois 60532 U.S.A. 1-800-78MOLEX amerinfo@molex.com Far East North Headquarters Yamato, Kanagawa, Japan 81-462-65-2324 feninfo@molex.com Far East South Headquarters
Jurong, Singapore
65-6-268-6868
fesinfo@molex.com

European Headquarters Munich, Germany 49-89-413092-0 eurinfo@molex.com Corporate Headquarters 2222 Wellington Ct. Lisle, IL 60532 U.S.A. 630-969-4550 Fax: 630-969-1352

Visit our Web site at http://www.molex.com

Doc No: ATS-638136100 Release Date: 03-09-10 Revision: A Revision Date: 03-09-10

UNCONTROLLED COPY

Page 2 of 2