

Excellent Integrated System Limited

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

[NXP Semiconductors](#)

[TWR-PROTO](#)

For any questions, you can email us directly:

sales@integrated-circuit.com



Prototyping Module

Quick Start Guide




How to build your Tower

1. Press the card edge connector of each Tower module into a slot on the elevator—take care to match all the primary card edges and plug them into a functional elevator. A module may be placed into any slot on the elevator.
2. Press another **elevator** board onto the **secondary** card edges.



TWR-PROTO features

- Access to all signals on primary and secondary elevator connectors for prototyping and signal probing
- Prototyping area for adding custom circuitry to Tower System
- Multiple 5V, 3.3V and GND connections



Learn more at www.freescale.com/tower

Freescale and the Freescale logo are trademarks or registered trademarks of Freescale Semiconductor, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2009.

Doc Number: TWRPROTOQSG / REV 0
Agile Number: 926-26187 / REV A

