

# **Excellent Integrated System Limited**

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

Molex Connector Corporation 0638671000

For any questions, you can email us directly: <u>sales@integrated-circuit.com</u>




**Distributor of Molex Connector Corporation: Excellent Integrated System Limited** Datasheet of 0638671000 - FINE ADJUST APPLICATOR Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

63867-1000 Fine Adjust Applicator



FineAdjust Applicator Specification Sheet Part No. 63867-1000




#### **FEATURES**

- Quick punch removal with the push of a button for fast and easy tooling change
- Applicator designed to industry standard mounting and shut height 135.80mm (5.346")
- Quick set-up time; plus the crimp height, track and feed adjustments can be set without removing the applicator from the press
- Fine adjustment allows users to achieve target with little effort by adjusting in increments of 0.15mm (.0006") for conductor crimp height and .063mm (.0025") for insulation height
- Independent adjustment rings allow users to quickly adjust the conductor or insulation crimp height without affecting each other
- Directly adapts to most automatic wire processing machines

#### SCOPE

| Terminal   | Wi    | ire Size        | Insulation         | Diameter  | Strip Length |         |  |
|------------|-------|-----------------|--------------------|-----------|--------------|---------|--|
| Series No. | AWG   | mm <sup>2</sup> | mm <sup>2</sup> mm |           | mm           | In.     |  |
| 94539-1000 | 20-24 | 0.50-0.25       | 2.20 Max.          | .087 Max. | 4.10-4.60    | .161181 |  |

#### **DEFINITION OF TERMS**



The above terminal drawing is a generic terminal representation. It is not an image of a terminal listed in the scope.



63867-1000 Fine Adjust Applicator

## **CRIMP SPECIFICATION**

| Terminal       | Bell ı | nouth   | Cut-off | Tab Max. | Conductor Brush |         |  |
|----------------|--------|---------|---------|----------|-----------------|---------|--|
| Series No.     | mm     | In.     | mm      | In.      | mm              | In.     |  |
| 94539-<br>1000 | .2030  | .008012 | .30     | .012     | .50 – 1.00      | .020040 |  |

|  | Terminal<br>Series No. | Bend up Bend down |   | Twist  | t Roll | Punch Width mm (Ref) |      |            |                     | Seam                   |  |  |
|--|------------------------|-------------------|---|--------|--------|----------------------|------|------------|---------------------|------------------------|--|--|
|  |                        | Degree            |   | Degree |        | Conductor            |      | Insulation |                     | Seam shall not be open |  |  |
|  |                        |                   |   |        |        | mm                   | In   | mm         | In                  | and no wire allowed    |  |  |
|  | 94539-1000 3 3         |                   | Л | g      | 1.42   | .056                 | 2.40 | .094       | out of the crimping |                        |  |  |
|  | 74337-1000             | 5 5               |   | 7      | 0      | 1.42                 | .050 | 2.40       | .074                | area                   |  |  |

After crimping, the conductor profile should measure the following.

| Terminal   | Wire Size |                 | Conductor |                   |           |              |           | Insulation        |           |                |      | Pull Force Min. |  |
|------------|-----------|-----------------|-----------|-------------------|-----------|--------------|-----------|-------------------|-----------|----------------|------|-----------------|--|
| Series No. |           | Crimp Height    |           | Crimp Width (Ref) |           | Crimp Height |           | Crimp Width (Ref) |           | ron ronce win. |      |                 |  |
| AWG        |           | mm <sup>2</sup> | mm        | In.               | mm        | In.          | mm        | ln.               | mm        | In.            | N    | Lb.             |  |
| 94539-1000 | 20        | 0.50            | 0.91-1.01 | .036040           | 1.50 Max. | .059 Max.    | 1.70-1.80 | .067071           | 2.45 Max. | .096 Max.      | 58.8 | 13.22           |  |
| 94539-1000 | 22        | 0.35            | 0.90-0.98 | .035039           | 1.50 Max. | .059 Max.    | 1.55-1.65 | .061065           | 2.45 Max. | .096 Max.      | 39.2 | 8.81            |  |
| 94539-1000 | 24        | 0.25            | 0.88-0.96 | .035038           | 1.50 Max. | .059 Max.    | 1.50-1.60 | .059063           | 2.45 Max. | .096 Max.      | 29.4 | 6.61            |  |

Pull Force should be measured with no influence from the insulation crimp.

The above specifications are guidelines to an optimum crimp.



63867-1000 Fine Adjust Applicator

### PARTS LIST


| ltem | Order No   | Engineering No. | Description                    | Quantity |  |  |
|------|------------|-----------------|--------------------------------|----------|--|--|
|      | 63867-1000 | 63867-1000      | FineAdjust Applicator (Fig. 1) | REF      |  |  |
| 1    | 63457-0024 | 63457-0024      | Conductor Punch                | 1 Y      |  |  |
| 2    | 63455-0026 | 63455-0026      | Conductor Anvil                | 1 Y      |  |  |
| 3    | 63454-0036 | 63454-0036      | Insulation Punch               | 1 Y      |  |  |
| 4    | 63456-0032 | 63456-0032      | Insulation Anvil               | 1 Y      |  |  |
| 5    | 63443-0002 | 63443-0002      | Cut-Off Plunger                | 1 Y      |  |  |
| 6    | 63443-0012 | 634430012       | Front Plunger Retainer         | 1 Y      |  |  |
| 7    | 11-24-1067 | 4996-4          | Cut-Off Plunger Spring         | 1        |  |  |
| 8    | 11-40-4039 | 8302-5          | Front Plunger Striker          | 1        |  |  |
| 9    | 63443-0021 | 63443-0021      | Lower Tooling Key              | 1        |  |  |
| 10   | 63443-6005 | 63443-6005      | Rear Cover                     | 1        |  |  |
| 11   | 11-18-4083 | 60707-8         | Front Cover                    | 1        |  |  |
| 12   | 63443-2515 | 63443-2515      | Anvil Mount                    | 1        |  |  |
| 13   | 63443-4025 | 63443-4025      | Wire Stop                      | 1        |  |  |
| 14   | 63443-0009 | 63443-0009      | Scrap Chute                    | 1        |  |  |
| 15   | 63800-4900 | 63800-4900      | FineAdjust Applicator          | 1        |  |  |
| 16   | N/A        | N/A             | M3 by 6Lg. SHCS                | 2**      |  |  |
| 17   | N/A        | N/A             | M4 by 6Lg. SHCS                | 1**      |  |  |
| 18   | N/A        | N/A             | M4 by 12Lg. BHCS               | 2**      |  |  |
| 19   | N/A        | N/A             | M4 by 16Lg. SHCS               | 1**      |  |  |
| 20   | N/A        | N/A             | M4 by 50Lg. SHCS               | 2**      |  |  |
| 21   | N/A        | N/A             | 3MM by 6Lg. Roll Pin           | 1**      |  |  |
| 22   | N/A        | N/A             | #10-32 by 1/4″Lg. BHCS         | 1**      |  |  |
|      | 63867-1070 | 63867-1070      | Tool Kit (All Y Items)         | REF      |  |  |

\*\* The following purchased parts are available from an Industrial supply company such as MSC (1-800-645-7270).



Distributor of Molex Connector Corporation: Excellent Integrated System Limited Datasheet of 0638671000 - FINE ADJUST APPLICATOR Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

63867-1000 Fine Adjust Applicator





63867-1000 Fine Adjust Applicator

#### NOTES

- 1. Molex recommends an extra perishable tooling kit be maintained at your facility.
- 2. Verify tooling alignment by manually cycling the press and Applicator before crimping under power. Check that all screws are tight.
- 3. Slugs, Terminals, Dirt and Oil should be kept clear of work area.
- 4. Wear safety glasses at all times.
- 5. For recommended maintenance refer to the FineAdjust Manual.

CAUTION: This applicator should only be used in a press with a shut height of 135.8 mm (5.346"). Tooling damage could result at a lower setting.

CAUTION: To prevent injury never operate this Applicator without the guards supplied with the press or wire-processing machine in place. Reference the press or wire processing manufacturer's instruction manual.

CAUTION: Molex crimp specifications are valid only when used with Molex terminals, applicators and tooling.

Molex Application Tooling Group 1150 E. Diehl Road Naperville, IL 60563 Tel: (630) 969-4550 Fax: (630) 505-0049

Visit our Web site at http://www.molex.com