## **Excellent Integrated System Limited**

Stocking Distributor

Click to view price, real time Inventory, Delivery & Lifecycle Information:

Molex Connector Corporation 0622018795

For any questions, you can email us directly: sales@integrated-circuit.com



## Distributor of Molex Connector Corporation: Excellent Integrated System Limited

Datasheet of 0622018795 - PRESSIN TOOL IMPACT ROUTE 6X12


Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

Impact™ Backplane Press-In Tool

Impact™
Backplane Module
Installation
Press-In Tool



# **Application Tooling Specification Sheet**



Order No. 62201-8795

#### **FEATURES**

- Polarized tool prevents product damage
- Tool provides uniform distribution of press force across entire pin array
- May be used as a stand-alone tool or mounted in an optional holder with other Molex press-in tools

#### **SCOPE**

<u>Products</u>: Impact™ Ortho Routable Backplane Signal Module Assembly, (6-Pair by 12 Column Assemblies). See Product List below for specific part numbers.


#### **Product List**

The following is a partial list of the product order numbers and their specifications this tool is designed to run. Updates to this list are available on <a href="https://www.molex.com">www.molex.com</a>.

Series No.	Guide Style	Columns	Assembly Order Number			
76989	Open	12	76989-1204	76989-1205	76989-1207	76989-1208
	Dual End Wall	12	76989-1224	76989-1225	76989-1227	76989-1228
	Right Open	12	76989-5204	76989-5205	76989-5207	76989-5208
	Right End Wall	12	76989-9204	76989-9205	76989-9207	76989-9208

## **Tool Setup**

Depending on the number of connectors to be installed and/or the press used, this tool can be used alone or with a group of press-in tools, mounted in a 62201-95XX rail (ordered separately). See Figure 1.



Doc No: ATS-622018795 Release Date: 04-22-13

Revision: A Revision Date: 04-22-13

**UNCONTROLLED COPY** 

Page 1 of 3

## Distributor of Molex Connector Corporation: Excellent Integrated System Limited

Datasheet of 0622018795 - PRESSIN TOOL IMPACT ROUTE 6X12

Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com

Impact™ Backplane Press-In Tool

#### **Tool Installation**

The 62201-95XX rail is available in a variety of lengths to accommodate multiple press-in tools.

Rail Part Number	Rail Overall Length		
62201-9501	24mm (0.94 in)		
62201-9502	72mm (2.83 in)		
62201-9503	156mm (6.14 in)		
62201-9504	216mm (8.50 in)		
62201-9509	254mm (10.0 in)		
62201-9511	305mm (10.0 in)		

Reference: This Press-In Tool is 24.1mm (0.95 in.) long.

## **Printed Circuit Board (PCB) Support**

The Impact™ connectors require up to 3.6kg (8 lb) of force per pin to press into the PCB. To prevent excessive PCB flexure and/or damage to the PCB, a support plate is strongly recommended directly beneath the connector hole pattern.

Due to the custom nature of every application, Molex does not offer any PCB support plate. The customer must furnish their own support plate.

When creating the PCB support plate, remember to allow clearance for the connector pins as they pass through the PCB thickness.

## **Press Equipment Recommendations**

Many types of presses can be used to install Impact™ connectors, but to assure consistent connector installation Molex recommends the following press criteria:

- 1. The capability to detect force variations as low as 4.5kg (10 lb) during the press-in cycle; excessive force measurements should stop the press-in cycle.
- 2. The rate of pressing can be regulated as low as 0.13mm (0.005 in) per second.
- 3. Press stroke control to within 0.25mm (0.010 in).
- 4. Total press stroke must be at least 19mm (0.75 in).
- 5. For statistical purposes, automatic collection of force and distance data.

Doc No: ATS-622018795 Release Date: 04-22-13 **UNCONTROLLED COPY** Page 2 of 3

Revision: A Revision Date: 04-22-13



## Distributor of Molex Connector Corporation: Excellent Integrated System Limited


Datasheet of 0622018795 - PRESSIN TOOL IMPACT ROUTE 6X12

Contact us: sales@integrated-circuit.com Website: www.integrated-circuit.com


Impact™ Backplane Press-In Tool

## **Tool Operation**

- Insert by hand the backplane signal module assembly (s) carefully into the PCB hole pattern. Make sure the connector(s) are oriented properly by confirming the location of the #1 circuit notch with respect to the PCB layout.
- 2. Insert the Press-In Tool making sure that the notch in this tool is inserted into the slot on top of the connector housing of the backplane signal module assembly. See Figure 2.



3. Using the application tool and an appropriate press, seat the header assembly until there is less than 0.10mm (.004 in) clearance between the bottom of the plastic housing and the surface of the PCB. See Figure 3.



There should be no broken stand-offs along the perimeter of the part (an indication of over-pressing).

**CAUTION**: To prevent injury, never operate any press without the guards in place. Refer to the press manufacturer's instruction manual.

**CAUTION**: Molex application tooling specifications are valid only when used with Molex connectors and tooling.

## **Contact Information**

For more information on Molex application tooling please contact Molex at 1-800-786-6539.

Visit our Web site at http://www.molex.com

Doc No: ATS-622018795 Release Date: 04-22-13 **UNCONTROLLED COPY** Page 3 of 3 Revision: A Revision Date: 04-22-13